

TABLE OF CONTENTS

1.	Ordering Codes.....	2
2.	Description	3
2.1	Features.....	3
3.	Installation / Safety Information.....	3
3.1	Solid State Relay Installation	4
3.2	Mounting Instructions.....	4
3.3	Electrical Connections	5
3.3.1	Current Transformer Installation	5
3.3.2	Internal Diagram	6
3.4	SSR Output Snubbers and Transient Protection	7
3.4.1	Solid State Relays (SSRs).....	7
3.4.2	Commutation Problems	7
3.4.3	dv/dt Problems.....	7
3.4.4	Snubber Sizing	7
3.4.5	MOVs and TVSs.....	7
3.5	Limited Warranty.....	7
4.	Operation	8
4.1	Power Supply.....	8
4.2	24V Power Fusing.....	8
4.3	Command Input	8
4.4	PWM Command Input	8
4.4.1	Input Fail-safe Protection.....	9
4.5	Line Voltage Compensation.....	9
4.6	Soft Change	9
4.6.1	Current Limit & Soft Change.....	9
4.7	Soft Start.....	10
4.1	Current Feedback / Current Limit.....	10
4.1.1	Current Transformer Input	10
4.1.2	Current Limit Adjustment Procedure.....	11
4.2	Voltage Limit	11
4.2.1	Voltage Limit Adjustment Procedure	11
4.3	Configuration Dipswitch	11
4.4	Control Output	12
4.5	OUT LED	13
4.6	LIM ON LED.....	13
4.7	Three Phase Operation	13
4.7.1	Three Phase Special Wiring Considerations	13
4.7.2	Three Phase Wiring of Command Inputs	14
4.8	Wiring Multiple Units in Single Phase Applications.....	14
4.8.1	Connecting Power & Commands In Parallel.....	14
5.	Electrical Specifications	15
6.	Mechanical Dimensions	15
7.	Contact Information.....	15
8.	WIRING DIAGRAM Single Phase (4-20mA, 0-5V, 0-10V Inputs).....	16
9.	WIRING DIAGRAM Single Phase (Potentiometer Input)	16
10.	WIRING DIAGRAM 3 Phase Inside Delta	17
11.	WIRING DIAGRAM 3 Phase 4 Wire Y	17

1. Ordering Codes

Part#	Description	Inputs
SSRMAN-1P-CL-50-2SC	SSR Mount Phase Angle Control Module, Volts, mA Input, Pot, Current limit to 50Amps, 2 second default soft change.	0-10V, 0-5V, 2-10V, 1-5V, 4-20mA, 0-20mA, Potentiometer
SSRMAN-1P-CL-100-2SC	SSR Mount Phase Angle Control Module, Volts, mA Input, Pot, Current Limit to 100Amps, 2 second default soft change.	0-10V, 0-5V, 2-10V, 1-5V, 4-20mA, 0-20mA, Potentiometer
SSRMAN-1P-CL-XXX-2SC-LIV	Same as above with linear voltage output response, instead of the standard output of linear power.	0-10V, 0-5V, 2-10V, 1-5V, 4-20mA, 0-20mA, Potentiometer
SSRMAN-1P-CL-50-2SC-REG	SSR Mount Phase Angle Control Module, Volts, mA Input, Pot, Current Regulation to 50Amps, 2 second default soft change.	0-10V, 0-5V, 2-10V, 1-5V, 4-20mA, 0-20mA, Potentiometer
SSRMAN-1P-CL-100-2SC-REG	SSR Mount Phase Angle Control Module, Volts, mA Input, Pot, Current Regulation to 100Amps, 2 second default soft change.	0-10V, 0-5V, 2-10V, 1-5V, 4-20mA, 0-20mA, Potentiometer

2. Description

The SSRMAN-1P-CL is a phase angle control module designed for use with standard footprint random fire SSRs (Solid State Relays). The module mounts directly on the SSR's input screws. The module operates by varying the firing point of the SSR's input based on the command input and the load current. The SSRMAN-1P-CL will not operate correctly with zero cross fired SSRs.

2.1 Features


- Provides true linear power output phase angle control with current limit
- Small (1.6x1.8") module mounts on the input terminals of an inexpensive SSR
- Command input accepts 4-20mA, 0-20mA, 0-10V, 2-10V, 0-5V, 1-5V, Pot, PWM
- Adjustable Current or Voltage Limit
- Configurable line voltage compensation increases stability of your process
- Configurable soft change for high inrush loads
- Automatic 50/60Hz operation
- Drives multiple solid state relays
- Single phase and three phase control

3. Installation / Safety Information

Responsibility for determining suitability for use in any application / equipment lies solely on the purchaser, OEM and end user. Suitability for use in your application is determined by applicable standards such as UL, cUL and CE and the completed system involving this component should be tested to those standards.




WARNING: FIRE HAZARD!! Even quality electronic components CAN FAIL KEEPING FULL POWER ON! Provide a SEPARATE (redundant) OVER TEMPERATURE SHUTDOWN DEVICE to switch the power off if safe temperatures are exceeded.



WARNING: HIGH VOLTAGE!! This control is installed on a Solid State Relay with high voltage on it. This control must be installed in a GROUND^{ED} enclosure by a qualified electrician in accordance with applicable local and national codes including NEC and other applicable codes. Provide a safety interlock on the door to remove power before gaining access to the device.

3.1 Solid State Relay Installation




Make sure that the voltage and current ratings of the Solid State Relay (SSR) are sized correctly for the load, otherwise a hazardous condition such as over-heating, failure of the SSR, fire or explosion may result. Contact the SSR manufacturer for more details.



The SSR must be mounted to a heat sink as per the SSR manufacturer's requirements, otherwise a hazardous condition such as over-heating, failure of the SSR, fire or explosion may result. Contact the SSR manufacturer for more details.

3.2 Mounting Instructions




SSRMAN SHOULD BE ORIENTED AS SHOWN AND SCREWED TIGHT TO INPUT TERMINALS

The SSRMAN mounts directly to the control input terminals of an SSR using two #6-32 screws. Some relays have short input screws and longer screws will required to reach through the contacts on the SSRMAN.

Be sure to observe the correct polarity when mounting the module (module should be positioned with the terminal blocks not over the SSR). The module should sit firmly on top of the SSR terminals when the screws are tightened.

3.3 Electrical Connections




See the WIRING DIAGRAMS at the end of this document. Make sure the module ordered is the correct module for the application before wiring.

Before wiring the module all Dip Switch settings for the command input and special features should be setup properly per the Dipswitch Configuration Section.

The terminal blocks on the sides of the SSRMAN for connecting 24V Power and the command signal can accept 16-30 AWG wire.

3.3.1 Current Transformer Installation




To use the current limit feature on the SSRMAN-1P-CL, the Current Transformer must be installed so that it can read the load current. Pass the load circuit wire through the hole in the Current Transformer as shown in the diagram. Use a tie wrap to fix the Current Transformer securely to the wire. Wire the Current Transformer Lead Wires to the CT1 and CT2 Terminals on the SSRMAN-1P-CL. Dipswitch Position#1 should be set to on for current feedback to work correctly.

! If the current transformer should become disconnected from the CT1 or CT2 terminals, no current feedback will be present and the load current will increase based on the command only.


3.3.2 Internal Diagram

Please reference the internal diagram below to be absolutely sure that your system wiring will be compatible with the control module. There were two versions produced that can be determined from the marking of the terminals. The current production is a drop in replacement for the early units (the wiring is the same).

Early Units:



Current Production:



3.4 SSR Output Snubbers and Transient Protection

3.4.1 Solid State Relays (SSRs)

AC output SSRs use either SCRs or TRIACS internally and even though many SSRs have internal snubber networks, we have found these to be insufficient for use in many inductive load applications. The addition of external properly sized snubbers has improved performance in many applications we have encountered.

3.4.2 Commutation Problems

When an SCR or TRIAC is used to control an inductive load, the load current lags the mains voltage. When the device turns off at zero current, the rate of rise of the reapplied voltage can retrigger the device and produce half cycling and blown fuses. To limit this rate of rise and obtain reliable commutation, an R-C (resistor–capacitor) snubber circuit should be connected in parallel with the SCR/TRIAC.

When firing transformer coupled loads, if the secondary is opened, the primary current may drop below the holding current for the SSR and/or the power factor may become too low for reliable firing. This can produce asymmetrical firing into the transformer primary and cause excessive current draw, heating of the transformer and blown fuses. To remedy this, a power resistor can be placed in parallel with the primary of the transformer to make sure the minimum holding current of the SSR is satisfied (~150mA) and that the power factor is above 0.5.

3.4.3 dv/dt Problems

When voltage transients occur on the mains supply or load of an SCR/TRIAC it can cause the device to turn on unexpectedly due to the fast rate of rise of voltage (dv/dt). This can result in false firing and half cycling of the load that can cause blown fuses when driving inductive loads. An R-C snubber circuit will help to limit the dv/dt seen by the device and will produce more reliable firing.

3.4.4 Snubber Sizing

When an SCR/TRIAC using an R-C snubber turns on, the capacitor is discharged through the resistor into the device resulting in high peak currents. It is critically important when sizing your snubber to make sure that the resistor value does not become so low that the ratings of the SCR/TRIAC are exceeded when the capacitor is discharged.

3.4.5 MOVs and TVSs

Metal Oxide Varistors and Transient Voltage Suppressors are both used on TRIACS/SCRs to “clamp” voltage spikes that can occur across the devices and damage them. Snubbers are not a substitute for MOVs/TVSs and vice versa. Snubbers and MOVs/TVs should be used together to get reliable performance and long life from the SCR/TRIAC application.

3.5 Limited Warranty

NuWave Technologies, Inc. warrant this product to be free from defect in workmanship and materials for a period of two (2) years from the date of purchase.

1. Should unit malfunction, return it to the factory. If defective it will be repaired or replaced at no charge.

2. There are no user serviceable parts on this unit. This warranty is void if the unit shows evidence of being tampered with or subjected to excessive heat, moisture, corrosion or other misuse / misapplication.
3. Components which wear or damage with misuse are excluded, e.g. relays.
4. NuWave Technologies, Inc. shall not be responsible for any damage or losses however caused, which may be experienced as a result of the installation or use of this product. NuWave Technologies, Inc. liability for any breach of this agreement shall not exceed the purchase price paid E. & O.E.

4. Operation

4.1 Power Supply

The SSRMAN-1P-CL power requirement is 24V AC +/-15% 47-63Hz. The module will not operate from a 24VDC power supply since it relies on the 24VAC supply for synchronization to the AC line. The 24VAC power input integrity is critical to the proper operation of the SSRMAN-1P. Noise or distortion of this power will affect the zero cross timing and thus accuracy of the output, especially in three phase applications. Using a split bobbin transformer for the 24VAC supply is recommended.

4.2 24V Power Fusing

Fusing may be accomplished by fusing each module separately or fusing groups of the modules with either primary or secondary fusing. The current draw of each SSRMAN-1P-CL is 65mA max.

4.3 Command Input

The SSRMAN-1P-CL can accept 4-20mA, 0-10V, 0-5V, and Potentiometer and PWM inputs. All command inputs are not isolated from the 24VAC power Input. The type of command input can be configured via the dipswitch. The default setting is 0-5V/potentiometer.

When wiring multiple SSRMAN-1P-CL's together, follow the guidelines in the Wiring Multiple SSRMAN-1P-CL's section.



Connecting 24V AC power to the command input will cause damage to the unit.

When 4-20mA is selected via the dipswitch, a 249 Ohm shunt resistor is present at the command input between the GND and VIN terminals. Be sure not to exceed 20mA DC on the input as damage to the unit may result. If the command input is wired to a 0-20mA or 4-20mA output of another device, the GND terminal must remain at the same potential as the negative lead of the current output from the other device, otherwise damage to the SSRMAN may result.

4.4 PWM Command Input

If the PLC or computer providing the PWM signal has 24V drive and the SSRMAN dipswitches switches are set to 0-10V, full output of the SSRMAN-1P-CL will be obtained at a 42% ~ (10V/24V x100%) duty cycle so rescaling in the PLC software is required. If the PWM command is 5V TTL drive, all of the command dipswitches should be set to off.

If the command is coming from the 5 volt SSR drive of a temperature / process controller, all of the command dipswitches should be set to off and a 1K resistor should be added in parallel with the command input. The output cycle time of the temperature / process controller should be set to as fast as possible (100 or 200mS max) and the soft change switch should be set to on.

4.4.1 Input Fail-safe Protection

If the signal sent to the SSRMAN-1P-CL's command input should become electrically open the control output will be forced to an off state.


4.5 Line Voltage Compensation

The SSRMAN-1P-CL's line voltage compensation keeps the power relatively constant on the load as the line voltage changes. The line voltage is measured via the 24VAC power applied to the SSRMAN-1P-CL module. To use the line voltage compensation feature properly, the 24VAC power transformer should be fed from the same mains as the load circuit to be controlled as per the wiring diagrams at the end of this document. Line voltage compensation can be enabled or disabled using the configuration dipswitch. The default setting is enabled (switch # 6 is OFF). To disable the Line Voltage Compensation, set switch # 6 to the ON position. Since most 24VAC transformer's voltage run a little bit high the nominal input voltage is approx 26-27VAC. Line voltage compensation works best when using the transformers we sell.


4.6 Soft Change

The soft change feature limits how quickly the output can change value. For inductive loads such as transformers, soft change is always required because it prevents inrush current associated with DC accumulation and saturation of the transformer. Soft Change is also useful on high inrush heaters such as Quartz, Molybdenum, Tungsten, or Graphite heaters.

Soft Change can be set on or off using the configuration dipswitch # 2. The default setting is off. Soft change times below or above 2 seconds are available and can be ordered by adding a -XSC to the ordering code where X is the time in seconds.



The Soft Change ramps the voltage up or down slowly over the soft change period.




4.6.1 Current Limit & Soft Change

The current can be used with soft change. If Current Limit and soft change are selected, the 2 seconds (or special ordered soft change time “-XSC”) will be applied with current limit.


4.7 Soft Start

The Soft Start feature ramps up to the command value over a period of seconds. If soft start is ordered, the soft start time resets if the command value goes to zero (less than 4% of the input range) or power is cycled. Soft start is useful on high inrush heaters such as Quartz, Molybdenum, Tungsten, or Graphite heaters.

Soft Start can be set on or off using the configuration dipswitch # 2. The default setting is off. Custom soft start times can be ordered by adding a “-XSS” to the ordering code where X is the time in seconds.



The Soft Start ramps the voltage up slowly over the soft start period.



4.1 Current Feedback / Current Limit

When the Current Limit feature is enabled (Dipswitch # 1 set to on) and the current transformer wired per the Current Transformer Input section below, the SSRMAN-1P-CL will allow the maximum current to be set via the Current Limit Potentiometer. The range of adjustment of the Current Limit potentiometer is 10 - 110% of full scale load current (110% = OFF, when the pot is turned fully clockwise). The full scale load current is defined by the CT turns ratio described in the Current Transformer Input section.

4.1.1 Current Transformer Input

The SSRMAN-1P-CL requires a 1000 turn current transformer wired to the CT1 and CT2 terminals to provide current feedback for the Current Limit features.

The Current Transformer (CT) input has a full scale of 100mA RMS, and 5V peak. When used with the 1000 turn current transformer, the output current can be set over the following ranges:

SSRMAN-1P-CL-50 (5 to 50 amps)

SSRMAN-1P-CL-100 (10 to 100 amps)



If the current transformer should become disconnected from the CT1 or CT2 terminals, no current feedback will be present and the current will increase based on the command only.

4.1.2 Current Limit Adjustment Procedure

The Current Limit is adjustable from 10% to 100% of the full scale current. Setting the Current Limit potentiometer half way corresponds to a current limit of approximately 50% of full scale. The best way to set the current limit is using a true RMS current clamp meter on the load circuit. With the command input set to approximately 100% (on startup) turn the current limit pot fully CCW. Then just turn the pot CW slowly until the desired max output on the clamp meter current is observed.

When the SSRMAN-1P-CL is actively holding back or “limiting” the load current, the RED “LIM ON” LED will become energized.

If the current limit LED begins to blink, the current transformer input is overloaded. Overload occurs if the peak current goes beyond 63A peak (50A version) or 125A peak on the (100A version). This will affect the accuracy of the current limit and if the indicator blinks continuously the SSRMAN-1P-CL module may become damaged.

4.2 Voltage Limit

The Voltage Limit feature comes standard on the SSRMAN-1P-CL and is enabled when the current limit is turned off (Dipswitch #1 off). The Voltage Limit feature is used in conjunction with the line voltage compensation feature to limit the actual voltage delivered to the load. The voltage limit is adjustable via an on board potentiometer. For this feature to work properly, line voltage compensation must be turned on and the power transformer for the SSRMAN-1P-CL must be connected to the same mains as the load power.

4.2.1 Voltage Limit Adjustment Procedure


The Voltage Limit is adjustable from 0% to 100% of the max load voltage. Setting the Voltage Limit potentiometer half way corresponds to a power limit of approximately 50% or a voltage limit of 70% of the max load voltage. The best way to set the voltage limit is using a voltmeter connected across the load. With the command input set to approximately 100% (on startup) turn the pot fully CCW. Then just turn the pot CW until the desired output voltage is achieved. For this feature to work as a true voltage limit, it is important that the Line Voltage Compensation be enabled (this is the OFF position of switch # 6).

If the line voltage compensation is set to OFF the voltage limit will act as a percentage of output limit and the absolute voltage limit will change with line voltage.

When the SSRMAN-1P-CL is actively holding back or “limiting” the command via voltage limit, the RED “LIM ON” LED will become energized.

4.3 Configuration Dipswitch

The configuration dipswitch is used for setting up the command input, line voltage compensation and soft change. Using a pen point gently push the switch up for OFF and down for ON according to the setup outlined in the table below.




Command Input	3	4	5
0-5V (Default)	OFF	OFF	OFF
Potentiometer	OFF	OFF	OFF
0-10V	OFF	OFF	ON
4-20mA	ON	ON	OFF
0-20mA	OFF	ON	OFF
1-5V	ON	OFF	OFF
2-10V	ON	OFF	ON
24V 5-20KHz PWM	OFF	OFF	ON

Feature to Enable	1	2	6
None	OFF	OFF	ON
Line Voltage Comp Enabled (default)			OFF
Soft Change		ON	
Current Limit	ON		
Voltage Limit	OFF		

4.4 Control Output

The SSRMAN-1P-CL SSR output drive is a DC pulsed current limited 10V/15mA (nominal) drive signal. This is more than enough current for driving most 3-32V standard SSRs, however it is still important to review the data sheet for the SSR you would like to use for compatibility with the SSRMAN-1P-CL's output drive. The control output can tolerate a momentary direct short. The following graph will allow you to verify the SSR's compatibility with the SSRMAN-1P-CL over wide input voltage variations.



SSRMAN-1P-CL Output Drive Current vs. SSR Input Voltage Drop

4.5 OUT LED

The SSRMAN-1P-CL's RED output LED will turn on when the output is on and increase in intensity as the power output is increased. Because the drive signal varies considerably to give linear power output, the LED should only be used as a rough indication of SSR Drive and not actual power output. The output LED is wired in series with the SSR's input. If there is a poor connection on the SSR input terminals or a problem with the SSR's Input, the output LED will not become energized.

4.6 LIM ON LED

When the SSRMAN-1P-CL is actively holding back or "limiting" the output due to any of the below listed conditions, the RED "LIM ON" LED will become energized:

LIM ON LED	TYPICAL CONDITION
ON Steady	Current Limit or Voltage Limit is active
ON briefly, then off	Current Limit limited the inrush on the load
Blinking 0.5Hz	Current input is overloaded
Blinking Other Than 1Hz	Command input is changing up and down, occurs with low frequency PWM inputs.

4.7 Three Phase Operation

Three SSRMAN-1P-CLs can be used to control three poles of a three phase load for inside delta or grounded wye configurations. The Module should be wired as shown in the wiring diagrams, using one power transformer for each leg to be controlled.

4.7.1 Three Phase Special Wiring Considerations

The SSRMAN-1P-CL derives its AC synchronization from the applied 24VAC power. Each 24VAC transformer's primary must be connected to the corresponding leg power to be controlled by each SSRMAN-1P-CL.

4.7.2 Three Phase Wiring of Command Inputs

The command inputs should be connected in parallel if 0-5V or 0-10V is selected and in series if 4-20mA is selected.

4.8 Wiring Multiple Units in Single Phase Applications

If more than one SSRMAN-1P-CL is to be used from a non-isolated or common command signals:

1. A common power transformer can be shared. If the input selected is 0-10V or 0-5V, the inputs should be wired in parallel.
2. If multiple units must be powered from one power transformer and 4-20mA input is selected, one module should be set for 4-20mA and the remaining modules should be set for 1-5V.
3. If the command is 4-20mA, and the command inputs are to be wired in series, a separate power transformer for each module is required to isolate the inputs.

4.8.1 Connecting Power & Commands In Parallel

When multiple SSRMAN-1P-CL power inputs and commands are wired in parallel, all of the GND and VIN terminals can be connected together follows:


Power:	Command:
PWR1---- PWR1---- PWR1----->	GND----GND----GND----->
PWR2---- PWR2---- PWR2----->	VIN-----VIN-----VIN----->

We do not guarantee operation of the SSRMAN-1P-CL with any other SSR control modules. Using them in the same circuit may cause either module to be damaged. Always refer to the Internal Diagram section to be sure that your wiring scheme will not cause damage to the unit.

5. Electrical Specifications

Control Range	1 – 98% power
Command Inputs	4-20Ma, 0-20mA, 0-10V, 2-10V, 0-5V, 1-5V, Pot, PWM
Input Impedance	10K Ω (0-10V), 250 Ω (4-20mA), 100K Ω (0-5V)
Control Output	SSR Drive, DC pulse, nominally 10V at 15mA
Response Time	20mS (with soft change disabled)
PWM Input Frequency Range	10Hz – 20KHz (below 5KHz requires soft change on)
PWM Input Level	5-30VDC
Output Linearity	+/-2%
External Potentiometer Res.	10K Ω -25K Ω
Line Voltage Comp. Range	+15%/-15% up to 100% output
Line Voltage Comp. Regulation	+/-3%
Current Limit Accuracy	+/-5% of full scale (50 or 100A)
Current Limit Response Time	~1.5 AC cycles
Soft Change Period	2 Seconds to reach 100% output (2SC version)
Voltage Limit Range	5-100% of max load voltage
Ambient Temperature Range	0 to 60 $^{\circ}$ C
Power Supply Voltage	24VAC +15/-15%
Power Consumption	65mA (Power consumption 1.6W MAX)
Line Frequency Range	47-63 Hz
Terminal Block wire Gauge	16-30 AWG
Terminal Block Material	Polyamide 6.6 UL 94 V-0

6. Mechanical Dimensions




1.6x1.8", Max Height is 0.6"

7. Contact Information

NuWave Technologies, Inc
 866-379-3597
www.nuwaveproducts.com


8. WIRING DIAGRAM Single Phase (4-20mA, 0-5V, 0-10V Inputs)

SSRMAN-1P-CL WIRING DIAGRAM (4-20mA, 0-5V, 0-10V INPUT)
SHOWING CURRENT FEEDBACK




9. WIRING DIAGRAM Single Phase (Potentiometer Input)

SSRMAN-1P-CL WIRING DIAGRAM (4-20mA, 0-5V, 0-10V INPUT)
SHOWING CURRENT FEEDBACK



10. WIRING DIAGRAM 3 Phase Inside Delta

SSRMAN-1P-CL WIRING DIAGRAM
3 PHASE INSIDE DELTA CONNECTION



11. WIRING DIAGRAM 3 Phase 4 Wire Y

SSRMAN-1P-CL WIRING DIAGRAM
3 PHASE 4 WIRE Y CONNECTION

